

AAS	Advanced Antenna Systems
ACI	Adjacent-Channel Interference
AES	Advanced Encryption Standard
AMC	Adaptive Modulation and Coding
ARQ	Automatic Repeat Request
ATA	Analog Telephone Adapter
BPSK	Binary Phase Shift Keying
BSSID	Basic Service Set Identifier (this is the MAC address of the wireless interface)
BS	Base Station
BWA	Broadband Wireless Access
CD	Client Device
CPE	Customer-Provided Equipment
DES	Data Encryption Algorithm
DHCP	Dynamic Host Configuration Protocol
DMZ	DeMilitarized Zone
DNS	Domain Name System
ESSID	Extended Service Set Identifier
ECC	Electronic Communication Committee
FDD	Frequency Division Duplex
FEC	Forward Error Correction
FFT	Fast Fourier Transform
FSL	Free Space Loss
FWA	Fixed Wireless Access
GIS	Graphical Information System
GSM	Global System for Mobile Communications
GPS	Global Positioning System
IP	Internet Protocol
ITU	International Telecommunication Union
LAN	Local Area Network
LED	Light Emitting Diode
LOS	Line-of-Sight
MANs	Metropolitan Area Networks
MAC	Media Access Control

MMDS	Multipoint Microwave Distribution System
MN	Mesh Node
NLOS	Non-Line-of-Sight
OFDM	Orthogonal Frequency Division Multiplex
OFDMA	Orthogonal Frequency Division Multiple Access
OLSR	Optimized Link State Routing (protocol)
PBX	Private Branch eXchange
PC	Personal Computer
PHY	Physical
PL	Path Loss
QAM	Quadrature Amplitude Modulation
QoS	Quality of Services
QPSK	Quadrature Phase Shift Keying
RFC	Request for comment
SISP	Site Specific
SNR	Noise to Signal Ratio
SS	Subscribers Station
SSH	Secure SHell
SSID	Service Set Identifier (Network name - All mesh nodes attempting to communicate with each other must share the same SSID)
SUI	Stanford University Interim
TDD	Time Division Duplex
TDM	Time Division Multiplexed
UHF	Ultra High Frequency
UMTS	Universal Mobile Telecommunication System
VHF	Very High Frequency
VSAT	Very small aperture terminal
VoIP	Voice over internet protocol
WAN	Wide Area Network
WAP	Wireless Access Point
Wi-Fi	IEEE 802.11 wireless standards. Trademark of the Wi-Fi Alliance
WMAN	Wireless Metropolitan Area Networks
WMN	Wireless Mesh Network

LAMPIRAN A

CONFIGURATION STEPS

1. Setting up your machine to obtain an IP address automatically

FOR WINDOWS USERS:

Click on “**start**” → click on “**Control Panel**” → click on “**Network Connections**” → right click on “**Local Area Connection**” → select “**Properties**” → select the “**General**” tab → scroll down the list and select “**Internet Protocol TCP/IP**” → click on “**Properties**” → select the “**General**” tab → select “**Obtain an IP address automatically**” → click on “**OK**” on the Internet Protocol (TCP/IP) Properties window → click on “**OK**” on the Local Area Connection Properties window.

2. Repairing your LAN connection

FOR WINDOWS USERS:

Click on “**start**” → click on “**Control Panel**” → click on “**Network Connections**” → right click on “**Local Area Connection**” → select “**Repair**” or for help on repairing a connection:

Click on “**start**” → click on “**Help and Support**” → in the search box type “Repairing LAN connection” and follow the instructions.

FOR LINUX USERS:

Open a terminal, grant yourself root privileges (e.g. on Ubuntu, type “`sudo`” or simply “`sudodhclient eth0`” and press [Enter]) and type “`dhclient eth0`”, and press [Enter]; `eth0` is your LAN interface name. You should see an IP address of `192.168.1.x`, (where `1 _ x <255`) otherwise go to the troubleshooting section of this document.

3. Checking for an IP address

FOR WINDOWS USERS

Click on “**start**” → click on “**Control Panel**” → click on “**Network Connections**” → right click on “**Local Area Connection**” → select “**Status**” → click on the “**Support**” tab. You should see the allocated IP address.

OR

Click on “**start**” → click on “**Run**” → type in cmd → press [Enter] → this will open up a command line window → type
`ipconfig /?` displays the help for this command
`ipconfig` displays summary configuration information
`ipconfig /all` displays full configuration information
`ipconfig /release` releases the IP address for the adapter
`ipconfig /renew` renew the IP address for the adapter

Spesifikasi dari *Wireless router linksys* WRT54GL adalah: *Linksys WRT54G (up to version 4.0)* atau *Linksys WRT54GL (version 1.0 or 1.1)*. Untuk WRT54G *version 5.0 flash memory* berkurang dari 4MB ke 2MB dan sebagai akibatnya kapasitas memory tidak mencukupi untuk *Freifunk firmware*. *Linksys WRT54GL* sekarang ini adalah peralatan mesh networking yang banyak dipakai. *Linksys WRT54GL* memerlukan suplai tegangan listrik sebesar 12V DC dengan arus sebesar 0,5 A. Kebutuhan daya ini merupakan kebutuhan *standard* untuk *embedded devices* dan *wireless access point*, sehingga menjadikannya *compatible* dengan *Power over Ethernet* (PoE).

Seperti yang terlihat pada Gambar 3.9, dibagian depan *wireless router* ini terdapat tombol *secure easy setup* (dengan label “Cisco System”) bertujuan untuk memperbolehkan *user* dengan mudah mengatur enkripsi jaringan *wireless*, dan menetapkan bahwa *user* menggunakan perangkat keras dari *vendor* yang berpartisipasi dalam program *secure easy setup*. Selain itu terdapat juga beberapa lampu indikator (LED) pada *wireless router*. Lampu indikator *power* menandakan bahwa *wireless router* sedang aktif atau menerima suplai daya. Lampu DMZ menandakan bahwa *wireless router* sedang dalam proses *booting*. Lampu LED WLAN dan Ethernet (nomor 1 sampai 4) merupakan lampu yang menandakan bahwa *port* tersebut sedang digunakan (aktif), dan lampu LED internet menandakan adanya koneksi ke *port WAN*.



Gambar Tampak depan *wireless router* WRT54GL^[16]

Pada bagian belakang terdapat tombol *reset*, tombol ini adalah tombol yang *default*-nya akan me-*reset* *wireless router* ke *setting* awal dari pabriknya. *Port ethernet* (1 – 4) digunakan untuk menghubungkan *router* dengan jaringan LAN yang ada dan dengan perangkat jaringan lainnya. *Port power* yang merupakan *input* untuk suplai daya juga terdapat pada bagian belakang ini, serta terdapat *port* internet yang dapat digunakan untuk menghubungkan ke internet. Hal ini dapat dilihat pada Gambar 3.10

Perangkat Mesh Client

Perangkat *mesh client* yang ideal untuk digunakan dalam *testbed* adalah *notebook/laptop*. Penggunaan laptop sebagai *mesh client* adalah agar dapat memperlihatkan fungsi sebagai *host* dan *router* yang dapat melakukan fungsi *routing* dan konfigurasi serta menyediakan aplikasi *end-user* pada pengguna jaringan. Spesifikasi minimal yang harus dimiliki oleh perangkat *mesh client* adalah sebagai berikut:


- 1) OS (*Operating System*) Windows XP/Vista/Windows 7,
- 2) Processor Pentium IV or higher,
- 3) Memory 256 Mb,
- 4) LAN *card* (port koneksi ethernet),
- 5) WLAN *card* / *Wireless modem*.

Laptop yang digunakan harus dilengkapi dengan kartu jaringan (LAN *card*) agar dapat dihubungkan dengan *wireless router* untuk masuk ke dalam *firmwarenya*, sedangkan *Wireless modem* dibutuhkan agar konsep *user* dapat terhubung dengan jaringan kapan saja dan dimana saja dapat terpenuhi.

System Settings ^[16]

- Step 1 : Klik “**Admin**” pada program
- Step 2 : Klik “**System**” untuk mengkonfigurasi *system settings*
- Step 3 : Pilih berdasarkan “**Host Name**” (yang nantinya merupakan nama identitas pada Lynksys – dengan nama ini merupakan alamat yang dipakai pada alat tersebut)
- Step 4 : Nama negara harus diisi sesuai dengan konfigurasi alat yang akan dipakai pada sistem jaringan di negara tersebut
- Step 5 : Biarkan pilihan lain secara *default*. Kemudian tekan “**Apply**”. Kemudian akan muncul :
- The changed settings are committed. The settings are active after the next Restart.
- Step 6 : Klik “**Restart**”.

Proses *restart* akan memakan waktu beberapa menit dan secara otomatis akan meng-refresh Linksys sesudah proses restart selesai. Kemudian akan muncul tampilan “*Freifunk.Net – Hello!*”, tetapi dengan catatan akan dinamakan kemudian dengan tampilan “[*Host Name*] –Hello!”



Gambar *Freifunk firmware - System settings*^[16]

Instalasi *Wireless Settings*^[16]

- Step 1 : Klik “**Admin**”
- Step 2 : Klik “**Wireless**” untuk mengkonfigurasikan *wireless interface*
- Step 3 : Pilih “**Static**” untuk “**WLAN Protocol**”
- Step 4 : Tentukan pilihan untuk “**WLAN-IP Address**”
- Step 5 : Tentukan pilihan untuk “**WLAN Netmask**”
- Step 6 : Tentukan pilihan untuk “**WLAN Default Route**” (jika ada,
kosongkan kalau *default*)
- Step 7 : Pilih “**Ad Hoc (Peer to Peer)**” untuk “**WLAN Mode**”
- Step 8 : Pilih jenis **ESSID**
- Step 9 : Pilih jenis **BSSID**
Catatan: Selalu *lock* BSSID. Alamat MAC bisa dipilih dari salah
satu *Linksys* dan menggunakan ini sebagai *mesh network*.
BBSID penting secara spesifik untuk menghubungkan *mesh
network* ketika ada kerusakan diantara 2 *network* yang
mengakibatkan koneksi menurun (lambat) dan kemudian akan
tersambung lagi.
- Step 10: Tentukan jenis *channel* yang dipilih, bisaanya nomor 1-13, namun
biasanya ditentukan berdasarkan *system setting* tiap negara bisa
berbeda. Umumnya bisa digunakan *channels* (1,6 atau 11). Untuk
mesh dipakai *channel* 6 dan *channel* 11 sebagai *backbone*.
- Step 11: Pilih “**Auto**” antara “**RX Antenna**” dan “**TX Antenna**”, pilih
antenna yang akan digunakan.

Step 12: Biarkan pilihan lain secara *default*. Kemudian tekan “*Apply*”.

Kemudian akan muncul :

The changed settings are committed. The settings are active after the next Restart.

Step 13: Klik “*Restart*”.

Proses *restart* akan memakan waktu beberapa menit dan secara otomatis akan meng-refresh Linksys sesudah proses restart selesai.

Catatan: *settings* dari step 1-10 haruslah sama dengan semua Linksys pada jaringan yang sama.



Gambar *Freifunk firmware - Wireless settings*^[16]

Instalasi LAN *Settings*^[16]

Step 1 : Klik “*Admin*”

Step 2 : Klik “*LAN*” untuk mengkonfigurasikan LAN *interface*

Step 3 : Pilih “*Static*” untuk “*LAN Protocol*”

Step 4 : Tentukan pilihan untuk “*LAN-IP Address*”

Step 5 : Tentukan pilihan untuk “*LAN Netmask*”(gunakan **255.255.255.0** kecuali jika mempunyai nilai berbeda pada *netmask*)

Step 6 : Tentukan pilihan untuk “*LAN Default Route*” (jika ada, kosongkan kalau *default*)


Step 7 : Tandai kotak dengan perintah *Disable “NAT”*

Step 8 : Tandai kotak dengan perintah *Disable “Firewall”*

Step 9 : Biarkan pilihan lain secara *default*. Kemudian tekan “*Apply*”
Kemudian akan muncul :

The changed settings are committed. The settings are active after the next Restart.

- Step 10: Klik “**Restart**”.
Proses *restart* akan memakan waktu beberapa menit dan secara otomatis akan meng-*refresh* Linksys sesudah proses *restart* selesai
- Step 11: (Lewatkan step ini jika melewatkannya step 10)
Setelah di *restart* koneksi tidak akan bisa digunakan. Setelah 10-15 sekon akan memperbaiki koneksi. (Lihat apendiks B)
- Step 12: (Lewatkan step ini jika melewatkannya step 10)
Di alamat bagian pada *browser*, pilih alamat “**LAN IP**” secara spesifik kemudian tekan [Enter]



Gambar Freifunk firmware - *LAN settings*^[16]

Instalasi OLSR *Settings*^[16]

Setelah melakukan proses instalasi *firmware* OpenWrt dan paket OSLR, tahap berikutnya adalah mengkonfigurasi jaringan dan OSLR agar dapat beroperasi sesuai dengan ketentuan *routing protocol* OSLR. Langkah-langkah yang dilakukan adalah sebagai berikut ini:

- 1) Memberikan pengalamatan pada setiap *mesh router* dan *mesh client*.
- 2) Melakukan konfigurasi parameter-parameter *wireless router* agar berjalan sebagai jaringan *mesh*.
- 3) Memberikan *packet forwarding rules* pada *mesh router*.

4) Konfigurasi pada OSLR.

5) Menjalankan OSLR.

Step 1 : Klik “**Admin**”

Step 2 : Klik “**OLSR**” untuk mengkonfigurasikan OLSR *interface*

Step 3 : Di dalam kolom teks “**HNA4**” isi dengan tiga oktet alamat dari LAN IP di ikuti dengan 0/24. (Misalkan jika alamat LAN IP adalah 10.2.4.1, kemudian isikan dengan 10.2.4.0/24)

Step 4 : Jika Linksys sudah tersambung dengan internet dan ingin menyambungkan node lain untuk mengakses internet juga, klik “**Enable**” untuk perintah dynamic gateway – “**DynGW**”

Step 5 : Biarkan pilihan lain secara *default*. Kemudian tekan “**Apply**” Kemudian akan muncul :

The changed settings are committed. The settings are active after the next Restart.

Step 10: Klik “**Restart**”.

Proses *restart* akan memakan waktu beberapa menit dan secara otomatis akan meng-refresh Linksys sesudah proses restart selesai

Catatan **Penting** : Walaupun tiap langkah *setting* yang lain melewatkkan proses *restart*, tapi pada poin ini Linksys harus di *restart*.




Gambar *Freifunk firmware - OLSR Settings*^[16]

LAMPIRAN B


PREDIKSI COVERAGE

AREA


1. Gambar 3.22 Prediksi *Coverage* Sektor 1 BS Gerlong




2. Gambar Prediksi *Coverage* Sektor 2 BS Gerlong




3. Gambar Prediksi *Coverage* Sektor 3 BS Gerlong




4. Gambar Prediksi *Coverage* BS Gerlong Sektor 3




5. Gambar Prediksi Best Server BS Gerlong




6. Gambar Prediksi Best Server Signal Strength BS Gerlong




7. Gambar Prediksi Downlink C/(N+I) BS Gerlong




8. Gambar Prediksi Coverage Modulasi 16 QAM BS Gerlong




9. Gambar Prediksi *Data Rate* Rata-rata BS Gerlong



10. Gambar Analisis *Best Server Signal Strength* 3 BS



11. Gambar Prediksi Coverage Modulasi 16 QAM 3 BS





INTERNATIONAL TELECOMMUNICATION UNION

ITU-T

TELECOMMUNICATION
STANDARDIZATION SECTOR
OF ITU

G.1010

(11/2001)

SERIES G: TRANSMISSION SYSTEMS AND MEDIA,
DIGITAL SYSTEMS AND NETWORKS
Quality of service and performance

End-user multimedia QoS categories

ITU-T Recommendation G.1010

ITU-T G-SERIES RECOMMENDATIONS
TRANSMISSION SYSTEMS AND MEDIA, DIGITAL SYSTEMS AND NETWORKS

INTERNATIONAL TELEPHONE CONNECTIONS AND CIRCUITS	G.100–G.199
GENERAL CHARACTERISTICS COMMON TO ALL ANALOGUE CARRIER-TRANSMISSION SYSTEMS	G.200–G.299
INDIVIDUAL CHARACTERISTICS OF INTERNATIONAL CARRIER TELEPHONE SYSTEMS ON METALLIC LINES	G.300–G.399
GENERAL CHARACTERISTICS OF INTERNATIONAL CARRIER TELEPHONE SYSTEMS ON RADIO-RELAY OR SATELLITE LINKS AND INTERCONNECTION WITH METALLIC LINES	G.400–G.449
COORDINATION OF RADIOTELEPHONY AND LINE TELEPHONY	G.450–G.499
TESTING EQUIPMENTS	G.500–G.599
TRANSMISSION MEDIA CHARACTERISTICS	G.600–G.699
DIGITAL TERMINAL EQUIPMENTS	G.700–G.799
DIGITAL NETWORKS	G.800–G.899
DIGITAL SECTIONS AND DIGITAL LINE SYSTEM	G.900–G.999
QUALITY OF SERVICE AND PERFORMANCE	G.1000–G.1999
TRANSMISSION MEDIA CHARACTERISTICS	G.6000–G.6999
DIGITAL TERMINAL EQUIPMENTS	G.7000–G.7999

For further details, please refer to the list of ITU-T Recommendations

Classification of performance requirements into end-user Quality of Service categories

Based on the target performance requirements identified in Appendix I, the various applications can be mapped onto axes of packet loss and one-way delay as shown in Figure 1. The size and shape of the boxes provide a general indication of the limit of delay and information loss tolerable for each application class.




Figure 1/G.1010 – Mapping of user-centric QoS requirements

It can be seen that there are eight distinct groupings which encompass the range of applications identified. Within these eight groupings there is a primary segregation between applications that can tolerate some information loss and those that can not tolerate any information loss at all, and four general areas of delay tolerance.

This mapping can be formalised in Figure 2, to provide a recommended model for end-user QoS categories, where the four areas of delay are given names chosen to illustrate the type of user interaction involved. Of course, it is possible that each category could be subdivided into further categories to provide a range of quality levels for a specific service, as has been done for conversational voice in ETSI TS 101329-2 [4].




Figure 2/G.1010 – Model for user-centric QoS categories

Table I.1/G.1010 – Performance targets for audio and video applications

Medium	Application	Degree of symmetry	Typical data rates	Key performance parameters and target values			
				One-way delay	Delay variation	Information loss (Note 2)	Other
Audio	Conversational voice	Two-way	4-64 kbit/s	<150 ms preferred (Note 1) <400 ms limit (Note 1)	< 1 ms	< 3% packet loss ratio (PLR)	
Audio	Voice messaging	Primarily one-way	4-32 kbit/s	< 1 s for playback < 2 s for record	< 1 ms	< 3% PLR	
Audio	High quality streaming audio	Primarily one-way	16-128 kbit/s (Note 3)	< 10 s	<< 1 ms	< 1% PLR	
Video	Videophone	Two-way	16-384 kbit/s	< 150 ms preferred (Note 4) <400 ms limit		< 1% PLR	Lip-synch: < 80 ms
Video	One-way	One-way	16-384 kbit/s	< 10 s		< 1% PLR	

NOTE 1 – Assumes adequate echo control.

NOTE 2 – Exact values depend on specific codec, but assumes use of a packet loss concealment algorithm to minimise effect of packet loss.

NOTE 3 – Quality is very dependent on codec type and bit-rate.

NOTE 4 – These values are to be considered as long-term target values which may not be met by current technology.

Based on information in the Bibliography (Appendix II), Table I.2 provides an indication of suitable performance targets for data applications.

Table I.2/G.1010 – Performance targets for data applications

Medium	Application	Degree of symmetry	Typical amount of data	Key performance parameters and target values		
				One-way delay (Note)	Delay variation	Information loss
Data	Web-browsing – HTML	Primarily one-way	~10 KB	Preferred < 2 s /page Acceptable < 4 s /page	N.A.	Zero
Data	Bulk data transfer/retrieval	Primarily one-way	10 KB-10 MB	Preferred < 15 s Acceptable < 60 s	N.A.	Zero
Data	Transaction services – high priority e.g. e-commerce, ATM	Two-way	< 10 KB	Preferred < 2 s Acceptable < 4 s	N.A.	Zero
Data	Command/control	Two-way	~ 1 KB	< 250 ms	N.A.	Zero
Data	Still image	One-way	< 100 KB	Preferred < 15 s Acceptable < 60 s	N.A.	Zero
Data	Interactive games	Two-way	< 1 KB	< 200 ms	N.A.	Zero
Data	Telnet	Two-way (asymmetric)	< 1 KB	< 200 ms	N.A.	Zero
Data	E-mail (server access)	Primarily one-way	< 10 KB	Preferred < 2 s Acceptable < 4 s	N.A.	Zero
Data	E-mail (server to server transfer)	Primarily one-way	< 10 KB	Can be several minutes	N.A.	Zero
Data	Fax ("real-time")	Primarily one-way	~ 10 KB	< 30 s/page	N.A.	<10 ⁻⁶ BER
Data	Fax (store & forward)	Primarily one-way	~ 10 KB	Can be several minutes	N.A.	<10 ⁻⁶ BER
Data	Low priority transactions	Primarily one-way	< 10 KB	< 30 s	N.A.	Zero
Data	Usenet	Primarily one-way	Can be 1 MB or more	Can be several minutes	N.A.	Zero
NOTE – In some cases, it may be more appropriate to consider these values as response times.						